

CRETEFX® DREAM FLECKS



The CreteFx Dream Flecks should be mixed 8:1 with CreteFx Dream Flecks Hardener.

Recommended Primer Systems: CreteFx WB 7000, CreteFx E, CreteFx P, or CreteFx MoistureShield in white

Final colors and pattern may vary due to slight batch to batch manufacturing variation, application techniques, environmental conditions, the surfaces being treated and other elements which may cause differences from the samples presented. All colors are representative only.