



CARE & USE GUIDE

SureStep™ Combi convertible step

Thank you for your purchase of Hawk Labs' SureStep™ Combi convertible step. The following are our standard care and use instructions for the SureStep™ Combi convertible step. Please feel free to contact the installer of this product or Hawk Labs with any questions you may have.

Do not use the tub or apply weight to the SureStep Combi convertible step for two (2) days after installation to allow for the adhesive to completely dry.

- Prior to first use, please inspect the bead of caulk around the perimeter of the SureStep™ Combi convertible step to ensure that a continuous caulk bead has been applied and that there are no cracks or areas where caulk is absent. Conduct a similar inspection of the perimeter adhesive every six (6) months thereafter.
- Prior to first use, please clean and rinse the bathtub to rid the area of any dust and/or particulates that may remain after installation.
- Do not fill the tub with water over the opening of SureStep™ Combi convertible step.
- Do not use the unit as a grab-bar or assistive device.
- For use as a full bath, apply the center insert and align the holes on the left and right side of the insert with the corresponding holes on the SureStep™ Combi convertible step frame. Press downward on the center insert to ensure the insert is fully compressed into position. Insert the rosette knobs on each side of the center insert and tighten the rosette knobs completely.
- For use as a step-in shower, unscrew and remove the 2 rosette knobs. Once unscrewed, lift and remove the center insert.
- When not in use, store the center insert with the seals facing up and not compressed.
- It is recommended that the unit be cleaned regularly with a gentle household cleaning agent. Do not use harsh cleansers or abrasive tools to clean the SureStep™ Combi convertible step.
- It is recommended to completely close the shower curtain prior to turning on water to prevent water from splashing outside the bathtub.
- As with any bathtub, children should not be left unattended in the bathtub.